

NEW XDS35i Dry Vacuum Pump



NEW XDS35i Dry Vacuum Pump

Rating: Not Rated Yet

Price:

Variant price modifier:

Base price with tax:

Price with discount:

Salesprice with discount:

Sales price:

Sales price without tax:

Discount:

Tax amount:

[Ask a question about this product](#)

Manufacturer: [Edwards](#)

Description

NEW XDS35i Dry Vacuum Pump

COMPLETELY DRY, LUBRICANT FREE VACUUM PUMP WITH VAPOR HANDLING

Part of the family of the BOC Edwards XDS Dry pump, the **XDS35i** provides a clean, dry vacuum, totally free of lubricants for non-hazardous applications.

The bearings are isolated from the vacuum environment by a patented bearing shield. Uniquely, there are no bearings, grease or oil under vacuum and no bearing purge is required. Controllable gas ballast is standard and makes the **XDS35i** suitable for pumping vapors. Even small quantities of condensed liquid are easily handled without problems.

The versatile **XDS35i** uses a scroll mechanism manufactured by BOC Edwards, the market leader in dry pumping products and technology. The pump is driven from a single phase power with an on-board inverter to control the motor speed. This provides the user with constant pumping speed anywhere in the world. Power consumption is very low and typically no other utilities are required. Closed loop temperature monitoring provides protection in high ambient conditions.

The **XDS35i** is truly user serviceable. With no oil to change and dispose of, annual maintenance can typically be completed in about 20 minutes without special tools.

Includes **ONE (1) YEAR WARRANTY**.

????????? ?????? : NEW XDS35i Dry Vacuum Pump
